



**Fitting instructions ROCKAIRLABS Varia seatpost mount for Canyon SP0077/SP0078 Aeroad bike**

The first step is to screw the adapter to your seat post using the two M4 x 14 mm screws (tighten the M4 screws with feeling, after tightening comes ab...The limiter is your threaded insert on your seat post. We recommend a maximum tightening torque of 3 Nm. Once you have finalised the height, a drop of threadlocker is recommended. If necessary, a drop of nail varnish will also work). Then screw the Garmin adapter to the seat post adapter using the self-tapping black screws - done!



**What is in the box?:**

- 1 piece Garmin Varia seatpost mount made of Rockairlabs plastic
- 2 pieces M4 x 14 hexagon socket screws
- 1 piece Garmin adapter
- 2 pieces M3 x 19 self-tapping screws for attaching the Garmin mount.

PS:

We look forward to receiving a picture of your assembly on our email or on our Instagram account. A rating on Google and or Shopvote also helps us a lot as a small company!

Are you looking for a personalised solution for your BTA / bottle cage for the seatpost? Talk to us!