



**Fitting instructions ROCKAIRLABS Varia seatpost mount long version for Canyon  
SP0077/SP0078 Aeroad Bike / RAL013**

Thank you for purchasing our Varia seatpost mount for your Aeroad bike.

Installation is simple: You screw the adapter to your seatpost with the two M4 x 14 mm screws (tighten the M4 screws with feeling, after tightening comes off....The limiter is your threaded insert on your seatpost. We recommend a maximum tightening torque of 3 Nm. A drop of screw locking varnish is recommended. If necessary, a drop of nail varnish will also work).

We have already screwed on the Garmin adapter for you. If you ever want to unscrew it, please use a high-quality Phillips screwdriver that matches the screw size.



**Scope of delivery:**

- 1 piece seat post mount "long" Garmin Varia made of Rockairlabs plastic
- 2 hexagon socket screws M4 x 14
- 1 piece Garmin adapter "high quality version, injection moulding) mounted.
- 2 pieces of self-tapping screws M3 x 19 for mounting the Garmin mount (mounted.)

**PS:**

We look forward to receiving a picture of your mount on our email or on our Instagram account.

**Also a rating on Google ! really helps us as a small player!**

Are you looking for a personalised solution for your BTA / bottle cage for the seat post? Talk to us!